



INSTALLATION INSTRUCTIONS

Part Number: YA-9024

SEE CATALOG FOR CURRENT APPLICATIONS

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® Filtercharger® seals properly.

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

INSTALLATION:

1. Remove the 10 screws holding the air box lid and remove the dirty air filter. (Figs. 1 & 2)
2. Remove any dirt or debris from inside the air box base.
3. Insert the K&N air filter into the slots in the air box lid as shown. (Fig. 3)
4. Due to inconsistencies in air boxes, apply a bead of supplied sealing grease across the bottom of the K&N air filter as shown. (Fig. 4) Also apply grease to the parting lines where the air box base and lid mate together. (Fig. 5)
5. Install the lid, with the K&N air filter in place, into the base using the side channels as guides as shown. (Fig. 6)

NOTE: Clean an area on the air box and apply the "K&N Stop" decal. The decal will notify others who may be working on this vehicle, that this is a washable/re-usable air filter.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



Fig. 1



Fig. 2



Fig. 3



Fig. 4



Fig. 5



Fig. 6

CLEANING:

K&N Engineering, Inc., suggests checking the air filter element periodically for excessive dirt build-up. Depending on your driving conditions, we recommend cleaning your air filter every 50,000 miles. To clean and re-oil, purchase our filter Recharger® service kit, part number 99-5050 or 99-5000 and follow the easy instructions.